

## VISCOSENSE<sup>®</sup> 2

Viscosity Sensor & Interface box

Valid for ViscoSense<sup>®</sup> 2 (serial numbers from 70000)

Instructions  
for  
installation,  
operation  
and  
maintenance



Publ. Nr. TIB-761-GB-0709  
Supersedes TIB-761-GB-0509

**VAF** VAF INSTRUMENTS  
*for quality and innovation*

**TO BE REALLY SURE**

# CONTENTS

1. PREFACE .....	3
1.1 General.....	3
1.2 Symbols.....	3
1.3 Copyright.....	4
2. SYSTEM DESCRIPTION .....	5
2.1 System description .....	5
2.2 System components.....	6
2.3 Principle of operation.....	7
3. TECHNICAL SPECIFICATION .....	8
3.1 Sensor.....	8
3.2 Sensor housing .....	8
3.3 Interface box.....	9
4. SAFETY INSTRUCTIONS .....	9
4.1 Safety precautions .....	9
5. UNPACKING .....	10
6. INSTALLATION.....	10
6.1 To record nameplate data .....	10
6.2 Conditions for correct working of the ViscoSense® 2 sensor .....	11
6.3 General installation recommendations.....	12
6.4 Mechanical installation .....	12
6.4.1 ViscoSense® 2 interface box.....	12
6.4.2 ViscoSense® 2 housing.....	12
6.4.3 To assemble ViscoSense® 2 sensor.....	14
6.5 Electrical installation .....	16
6.6 Connection of sensor to interface box.....	17
7. OPERATING INSTRUCTIONS .....	18
7.1 Initial start-up .....	18
7.2 Shut-down on heavy fuel oil .....	18
7.3 Shut-down on diesel oil.....	18
7.4 Routine start-up.....	18
8. MAINTENANCE .....	19
8.1 Routine maintenance .....	19
8.2 To clean the ViscoSense® 2 sensor .....	19
8.2.1 General procedure.....	19
9. REPAIR OR REPLACEMENT .....	20
9.1 Repair .....	20
9.2 Replacement.....	20
10. TAKE OUT OF SERVICE .....	21
11. REMOVAL AND STORAGE OF EQUIPMENT.....	22
12. MALFUNCTION AND SEND FOR REPAIR.....	22

13.	ENVIRONMENT .....	22
14.	DISPOSAL.....	22
15.	TROUBLE SHOOTING .....	23
15.1	Disconnection the sensor.....	23
15.2	General trouble shooting.....	24
15.3	PI setting errors (for additional viscosity controller) .....	25
15.4	How to take a HFO sample for analysis .....	26
15.5	Diagnostic information .....	26
16.	CERTIFICATES.....	29
17.	DRAWINGS.....	30
17.1	ViscoSense <sup>®</sup> 2 sensor and sensor housing .....	30
17.1.1	ViscoSense <sup>®</sup> 2 sensor housing with sensor installed .....	30
17.2	ViscoSense <sup>®</sup> 2 interface box .....	33
17.2.1	ViscoSense <sup>®</sup> 2 interface box .....	33
18.	ABBREVIATIONS .....	34
19.	PARTS LISTS .....	35
19.1	ViscoSense <sup>®</sup> 2 sensor .....	35
20.	WARRANTY CONDITIONS .....	36
21.	ENCLOSURE.....	38
21.1	Recommendations for a good working booster unit .....	38

# 1. PREFACE

## 1.1 GENERAL

This manual contains instructions for installation, operation and maintenance (IOM) of the VAF ViscoSense<sup>®</sup>2 viscosity sensor and interface box.

For IOM information of associated equipment supplied by VAF Instruments, refer to the separate manual supplied with those products.

This manual contains important information for the installer, the operator and for your maintenance department.



To ensure safe and correct installation and operation, read this manual completely before installing the equipment and starting operations.



ViscoSense<sup>®</sup>2 sensor (from serial numbers 70000) and interface box (from serial numbers 1480000) are not interchangeable with previous model ViscoSense<sup>®</sup>.

For any additional information contact:

VAF Instruments B.V.  
Amstelwijkstraat 21, NL-3316 BB Dordrecht (Sales/Office)  
Pieter Zeemanweg 131, NL-3316 GZ Dordrecht (Warehouse/Factory)  
P.O. Box 40, NL-3300 AA Dordrecht  
The Netherlands  
Or your local authorized VAF dealer.  
Their addresses can be found on [www.vaf.nl](http://www.vaf.nl)

Tel. +31 78 618 3100  
Fax +31 78 617 7068  
E-mail: [sales@vaf.nl](mailto:sales@vaf.nl)  
Internet: [www.vaf.nl](http://www.vaf.nl)



## 1.2 SYMBOLS

The following symbols are used to call attention to specific types of information.



A warning to use caution! In some instances, personal injury or damage to the ViscoSense<sup>®</sup>2 unit or control system may result if these instructions are not followed properly.



An explanation or information of interest.

### 1.3 COPYRIGHT

This technical manual is copyrighted with all rights reserved.

While every precaution has been taken in the preparation of this manual, no responsibility for errors or omissions is assumed. Neither is any liability assumed for damages resulting from the use of the information contained herein. Specifications can be changed without notice.

ViscoSense® is a registered trademark of VAF Instruments B.V.

Teflon® is a registered trademark of Dupont.

## 2. SYSTEM DESCRIPTION

### 2.1 SYSTEM DESCRIPTION

ViscoSense<sup>®</sup>2 is, besides other applications, intended for use in fuel oil treatment systems to obtain a correct measurement and control of the fuel oil viscosity.

Figure 1 shows a typical fuel treatment system with return line from the engine. In this system, the degassing/mixing tank operates as a fuel buffer, ensuring gradual changes of viscosity which results in a stable control of the viscosity. The ViscoSense<sup>®</sup>2 sensor is used to measure the actual viscosity of the fuel oil. The signal from the sensor is compared to the setpoint of a viscosity controller, which regulates the output of the fuel heater via a control element (steam or thermal oil valve, or electric heater cabinet).




Figure 1 Typical example of an automatic control system using steam or thermal oil heater

## 2.2 SYSTEM COMPONENTS

The ViscoSense<sup>®</sup>2 viscosity system consists of:

- the combined viscosity and temperature measuring sensor
- the sensor housing
- Interface box

The sensor housing is made of ductile iron and has flanges for direct mounting in the fuel line. The sensor itself is made of stainless steel and is mounted in the housing. Two parts of the sensor, the sensor head and flowtube have a special Teflon<sup>®</sup> coating. It is supplied with 5 metres of signal cable for connection to the interface box. The ViscoSense<sup>®</sup>2 Interface box is a wall mount electronic unit, processing the signals to and from the sensor. It provides 4..20 mA signals for remote read-out of viscosity and temperature for a controller or other system elements. See separate technical manuals for a description of these components.




Figure 2 ViscoSense<sup>®</sup>2 components

## 2.3 PRINCIPLE OF OPERATION

The operating principle of the sensor is that of a torsion pendulum. The sensor consists of a stainless steel driver / sensor head (1), attached to the base plate (2) by means of a tubular torsion spring (3). In the head, one pair of piezo elements (driver piezos) (4) actuates the pendulum at its torsional resonance frequency, while another pair (the receiver piezos) probes the actual movement of the head. In a low viscosity medium, like air the resonance frequency is in the range of 1600 Hz. In a high viscosity medium the movement of the head is damped by the liquid. Consequently, the resonance frequency slightly shifts towards lower frequencies, whilst the width of the resonance peak increases, which is a measure for the viscosity.

A flow tube (5) is placed around the pendulum, to protect it against mechanical damage. The flowtube inlet ensures a constant new supply of liquid for a correct measurement.




Figure 3 ViscoSense®2 sensor

### 3. TECHNICAL SPECIFICATION

#### 3.1 SENSOR

Viscosity range	0 .. 25/50 mPa.s (other ranges on request)
Maximum operating temperature	180°C
Temperature transmitter	PT 100 element
Accuracy	
Viscosity	+/- 2% instantaneous or 0.5 mPa.s
Temperature	± 1°C
Measuring range	0-200°C
Material	
Sensor	Stainless steel 316L
Coating	Teflon®
Signal cable	length 5 metres, integrated with sensor
Protection class	IP65
Weight	1 kg



#### Warning

For hazardous zone I and II, the ViscoSense® Ex d version is required.  
(See separate technical manual TIB-769)

#### 3.2 SENSOR HOUSING

Material housing	ductile iron
Flange connections	DN 50 mm (2"), DIN, ANSI or JIS DN 65 mm (2,5"), DIN, ANSI or JIS DN 80 mm (3"), DIN, ANSI or JIS DN 100 mm (4"), DIN, ANSI or JIS
Maximum pressure rating	40 bar
Weight	2" approx. 10 kg 2,5" approx. 11 kg 3" approx. 12 kg 4" approx. 13 kg

### 3.3 INTERFACE BOX

Supply voltage	115/230 VAC, 50/60 Hz selectable (Fluctuations should not exceed $\pm 10\%$ of the nominal value)
Power consumption	17...25 Watt
Output	
Viscosity	Active output 4...20 mA, current loop
Range	0-25/50 mPa.s (depending on range ViscoSense <sup>®2</sup> ) maximum load 400 Ohm
Temperature	Active output 4...20 mA, current loop
Range	0-200° C, maximum load 400 Ohm
Response time	Less than 1 minute
Resolution	0.1 mPa.s
Ambient temperature	-20... + 55 °C
Humidity range	0-95% RH
Protection class	IP 65
Mounting	Wall mounting
Cable connections	
Power supply	Cable dia. 6-12 mm
Output signals	Cable dia. 5-10 mm
Wiring supply	1.5 mm <sup>2</sup>
Output	24 AWG or 0.25 mm <sup>2</sup>
Installation category	I acc. to IEC 1010-1
Pollution degree	1 acc. to IEC 664
Ventilation requirements	no special requirements
Weight	2,9 kg

## 4. SAFETY INSTRUCTIONS

### 4.1 SAFETY PRECAUTIONS

To ensure the safety of personnel and equipment:

- Always follow the safety and installation recommendations in this manual.
- Always use personal protective means when working with hot, aggressive and toxic process liquids.
- Always use insulated tools when working on electrical installations.
- Ensure that local safety regulations are met when installing and operating the equipment.
- All personnel who operate and service the equipment should read this manual completely and make themselves acquainted with the equipment before installing or operating the equipment.
- The ViscoSense<sup>®2</sup> sensor body will heat up to the process temperature; do not touch the body housing while process is running!

## 5. UNPACKING

Let the instruments acclimatize in the location where they are going to be installed for at least one hour inside their shipment box. This is to avoid moisture buildup inside the instrument, or on the connectors and wires.

When the equipment is taken out of the box, please leave the transport locking cap and the outside protection, in place as long as possible to avoid any damage.

The ViscoSense<sup>®</sup>2 sensor has a special Teflon<sup>®</sup> coating on the pendulum and the flow tube. Damage of the coating will influence the working of the sensor.



Special care should be taken not to scratch or damage the Teflon<sup>®</sup> coating.

The transport locking cap and the outside protection should be stored, in the unlikely event the equipment has to be returned for repair.

Dispose of the packing material should be done according to the laws of the country where the equipment is installed, or according to the rules that are applicable on the vessel.



Figure 4 Transport locking cap



Figure 5 Outside protection

## 6. INSTALLATION

### 6.1 TO RECORD NAMEPLATE DATA


Before installing a ViscoSense<sup>®</sup>2 system, record type and serial numbers as stamped on the ViscoSense<sup>®</sup>2 sensor and interface box.



Always quote the instrument serial number and the variant number when contacting the factory or local service representative.

A ViscoSense<sup>®</sup>2 unit may be part of a complete VAF viscosity control system. For information and instructions covering the other components of this system, refer to the separate technical manuals as supplied with these components.


For identification purposes it is recommended to record also nameplate data of other ViscoSense<sup>®</sup>2 system components here.



Housing:  
 Serial number: \_\_\_\_\_  
 Variant: \_\_\_\_\_



Sensor:  
 Serial number: \_\_\_\_\_



Interface Box:  
 Serial number: \_\_\_\_\_  
 Model: \_\_\_\_\_

## 6.2 CONDITIONS FOR CORRECT WORKING OF THE VISCOSENSE<sup>®</sup>2 SENSOR

The flow is recommended to be in-between the maximum and minimum fluid flow rate as mentioned in chapter 21.1.

The ViscoSense<sup>®</sup>2 housing should be placed in such a way, that no air can be trapped in the housing. This can easily happen if the inner diameter of the piping is smaller than the inner diameter of the ViscoSense<sup>®</sup>2 housing, if it has been installed horizontally.

If the inner diameter of the piping is different than the inner diameter of the ViscoSense<sup>®</sup>2 housing, the transitions between the two diameters should be tapered.

The fluid should be homogenous.

It should not contain any air bubbles or foam.

The fluid should not contain any chemicals or solid particals that can damage Teflon<sup>®</sup>.

## 6.3 GENERAL INSTALLATION RECOMMENDATIONS

- Mount the ViscoSense<sup>®</sup>2 housing as low as possible, in the fuel system.
- Compare your process variables with the specifications. Make sure these are compatible!
- Pressure pulsations and variations should be avoided as much as possible.
- Mechanical vibrations should be avoided as much as possible.
- No special tools are required to install the ViscoSense<sup>®</sup>2. Ensure that your standard tools are fit for the job.
- Make sure that the working environment is clean. Ensure that no dirt can enter the sensor.
- Insulate the pipes and the sensor housing well, to avoid any temperature loss of the fluid.
- When fuel viscosity is 500 mPa·s or thicker it is recommended to wrap steam tracing with sufficient capacity, or 20 Watts/metre resistance wiring around the ViscoSense<sup>®</sup>2 housing.
- VAF ViscoSense<sup>®</sup>2 sensor and interface box are precision instruments. Handle them with care.



Do not unscrew the cable gland on the top of the ViscoSense<sup>®</sup>2 sensor or disconnect the cable from the sensor. This will violate the correct operation of the ViscoSense<sup>®</sup>2 sensor.



Take care that the pendulum is not damaged and the torsion tube not bent by mechanical force.  
This will violate the ViscoSense<sup>®</sup>2 signal.

## 6.4 MECHANICAL INSTALLATION


### 6.4.1 ViscoSense<sup>®</sup>2 interface box

1. Install the ViscoSense<sup>®</sup>2 interface box in a suitable location, free from excessive vibrations, humidity and excessive temperature variations.
2. The maximum distance between sensor and the interface box is determined by the cable length from the sensor, being approx. 5 metres.
3. Allow sufficient space for installation of cables and for servicing.


### 6.4.2 ViscoSense<sup>®</sup>2 housing

1. Remove dust caps from sensor housing and install housing stress-free, with shut-off valves and bypass valve in the fuel piping as illustrated in Figure 6. Take care that the flow direction is in accordance with the indication on the housing (inlet, outlet and arrow) as illustrated in figure 8. Support inlet and outlet piping sufficiently.  
These shut-off valves and bypass valve are not furnished by VAF Instruments.

2. Note that the distance between fuel heater and sensor housing inlet should not exceed 4 metres.
3. To protect the instrument from excessive vibrations, which can cause malfunctioning of the instrument, it is recommended to:  
Install the ViscoSense<sup>®</sup>2 as low as possible in the fuel system close to a solid structure or beam.  
Install suitable pipe clamps at both sides of the ViscoSense<sup>®</sup>2 sensor.
4. Allow at least 50 cm clearance to the sensor housing, to be able to take out the measuring sensor for service.
5. The sensor needs a stable environment to act as a counterweight for the pendulum movement. The support must prevent movement and excessive vibrations of the ViscoSense<sup>®</sup>2 housing, especially movement in the direction of the pendulum movement (see drawing- angular movement around the sensor axis). Therefore there must be two supports to the inlet and outlet perpendicular to the pipe and perpendicular to the ViscoSense<sup>®</sup>2. If one support would be used the lateral vibrations would be converted to angular vibrations and the situation would be made worse instead of better.



*Figure 6 Sensor installation diagram*



The angular position of the supports must always be 90° in relation to the sensor.  
 The distance from the flange to the support should be two times the diameter of the pipe.

ViscoSense®2 size	T. Max.	L. Max.
50 mm (2")	350 mm	150 mm
65 mm (2 ½")	400 mm	160 mm
80 mm (3")	400 mm	165 mm
100 mm (4")	450 mm	185 mm

Figure 7 Sensor installation diagram

#### 6.4.3 To assemble ViscoSense®2 sensor

1. Check the O-ring for damage, before installing the ViscoSense®2 sensor. Replace if necessary. Make sure only one o-ring is installed.
2. Remove transport locking cap from bottom side of flowtube.
3. Please make sure not to damage the Teflon® coating during installation.



Without the transport locking cap the sensor is not protected against excessive mechanical shocks which can occur during handling.

4. Install sensor carefully in housing with the flow tube inlet facing the flow, illustrated in figure 8.



Make sure the flow tube inlet is pointing towards the inlet of the sensor housing, see figure 8.

The sensor will not work correctly if installed wrongly.



Check if the position of the hole inside the housing and the fixation pin on the sensor match.

5. Tighten the nut (1) by hand. If there is a temperature difference between the sensor and the housing you should wait until they have the same temperature before tightening the nut.

6. Tighten the nut (1) with a wrench with a recommended torque of 100 Nm.



Make sure that all flange bolts and nuts are tightened correctly before re-pressurizing the system.



See chapter 15.1

7. The ViscoSense<sup>®</sup>2 system is now ready for electrical installation.




Figure 8 ViscoSense<sup>®</sup>2 sensor assembly

## 6.5 ELECTRICAL INSTALLATION



Provide correct supply power to the interface box.



In order to maintain proper EMC protection a shielded cable should be used for 4-20 mA output signals. Recommended cable: twisted pair individually screened conductor (24 AWG or 0.25mm<sup>2</sup>) stranded wire, overall screen and PVC insulated.



For correct installation a suitable isolation switch shall be installed in the supply line as near as possible to the equipment. Maximum fuse current 16A.



To avoid signal grounding problems it is not recommended to connect more than one device to each 4-20 mA output of the interface box.

1. Remove cover from interface box.



Check power selector switch for correct position in accordance with the power source to be supplied.



Figure 9

2. Feed cable from ViscoSense<sup>®2</sup> sensor through gland and connect wires to terminal J6 in accordance with Figure 12.
3. Feed cable for 4-20 mA viscosity and temperature output signals through the cable glands and connect wires to terminal J1 in accordance with Figure 12. When no temperature output is connected to 4 and 5 on J1 (Figure 12), terminals 4 and 5 must be connected together with a wire link.
4. Feed cable for main power supply through cable gland and connect wires to terminal J2 in accordance with Figure 12.



To maintain proper EMC protection the cable glands provided with the interface box should not be exchanged for cable glands of any other make/type.

5. Make sure that all connectors are properly seated before closing the cover again.
6. Close the cover of the interface box.

## 6.6 CONNECTION OF SENSOR TO INTERFACE BOX




Figure 10 Tighten the cable gland with a spanner




Figure 11 Install the numbered wires in the appropriate terminals of Terminal J6, see figure 12




Figure 12 External connections at interface box

## 7. OPERATING INSTRUCTIONS




Figure 13

### 7.1 INITIAL START-UP

The initial start-up should always be done with diesel oil.

1. Fill the complete fuel system with diesel oil.
2. Open block valves (K and M) and bypass valve (L)
3. Allow diesel oil to enter the fuel system
4. Vent the fuel system
5. Start the booster pump in the fuel system and after approximately 15 minutes close bypass valve (L)
6. Switch on power supply to the ViscoSense<sup>®</sup>2 system. Depending upon the viscosity of the liquid it can take up to 30 seconds, before the first reading appears. This is due to the automatic signal gain control.
7. Gradually change over to HFO.

### 7.2 SHUT-DOWN ON HEAVY FUEL OIL

Maintain heat tracing on the ViscoSense<sup>®</sup>2 sensor housing after shut-down, to prevent clogging of the fuel to the sensor internal parts.

### 7.3 SHUT-DOWN ON DIESEL OIL

No special actions on the ViscoSense<sup>®</sup>2 unit are required.

### 7.4 ROUTINE START-UP

Make sure that the power is on.

No other special actions on the ViscoSense<sup>®</sup>2 unit are required.

## 8. MAINTENANCE

### 8.1 ROUTINE MAINTENANCE

Under normal conditions the ViscoSense<sup>®</sup>2 interface box requires no maintenance.

“Normal” means;

- A clean operating environment
- ViscoSense<sup>®</sup>2 interface box installed in accordance with the installation instructions given.
- Operation of the ViscoSense<sup>®</sup>2 interface box and related control system in accordance with this manual and other related publications
- Uninterrupted power supply at normal specified values.

### 8.2 TO CLEAN THE VISCOSENSE<sup>®</sup>2 SENSOR



When removing a ViscoSense<sup>®</sup>2 sensor from the piping system precautions must be taken to prevent personal injuries and damage to the sensor and process installation.



See chapter 15.1.

#### 8.2.1 General procedure

1. Change over to manual viscosity control.
2. Shut off flow through the ViscoSense<sup>®</sup>2 sensor, by closing the valves on both side of the sensor housing.
3. Switch off power supply to the ViscoSense<sup>®</sup>2 interface box.
4. If possible drain and empty the piping system.



Although the flow has been shut off, the ViscoSense<sup>®</sup>2 housing can still be under pressure and hot. If the sensor is removed from a sensor housing which has not been de-pressurized, hot oil will spray out.

5. Unscrew the ViscoSense<sup>®</sup>2 sensor from its housing by loosening nut 1 (Figure 8 ViscoSense<sup>®</sup>2 sensor assembly).
6. Take out the ViscoSense<sup>®</sup>2 sensor.
7. Do not remove the flow tube, do not stick any object in between the flow tube and pendulum.
8. Flush the space between the tube and the pendulum with diesel oil or non aggressive cleaning detergent.



Take care that the pendulum is not damaged or the torsion tube bent by mechanical force.



**NEVER** use abrasive materials like sandpaper, files etc., to clean the flow tube. This will damage the Teflon<sup>®</sup> coating beyond repair.

9. For the re-installation of the sensor in the sensor housing please follow the instructions in chapter 6.

## 9. REPAIR OR REPLACEMENT

### 9.1 REPAIR

The ViscoSense<sup>®</sup> 2 sensor and interface box can not be repaired on site. They will be either exchanged for a spare unit or send back to VAF Instruments.

### 9.2 REPLACEMENT

When the sensor or interface box is replaced, we refer to chapter 5 and 6 for unpacking and installation instructions.

If the sensor is replaced, this will require that the correct settings for this sensor are made in the interface box. To make the correct settings, a spare sensor is supplied together with a dongle, which can be connected into the interface box.



Please note that the power supply should be connected to the interface box, when using the dongle. Please take necessary precautions to avoid personal injury.

Procedure for using the ViscoSense<sup>®</sup> 2 dongle:

1. Open the interface box
2. Insert the dongle into the interface box in the 9-pin serial connector (fig. 14)



Figure 14

3. Switch on the dongle (fig. 15). The red LED indicator on the dongle will burn now.



Figure 15

4. Wait until the green LED indicator on the dongle starts blinking and switch off the dongle. If the green LED indicator does not start blinking, please repeat steps 2 – 4.
5. Close the interface box and the system is ready for use. The dongle is meant to be used for 1 sensor only, and can be disposed according to local rules. The dongle contains electronic components and a small battery.

## 10. TAKE OUT OF SERVICE

Disconnect the power to the interface box. The ViscoSense<sup>®</sup>2 sensor should be taken out of the sensor housing and cleaned. See maintenance section for cleaning instructions. To protect the pendulum from damage due to mechanical shocks, the transport locking cap should be carefully placed in-between the flow tube and the pendulum.



Figure 16

## 11. REMOVAL AND STORAGE OF EQUIPMENT

Disconnect the power to the interface box. Disconnect the electrical connections of the sensor, outputs and power inside the interface box. The ViscoSense<sup>®</sup>2 sensor should be taken out of the sensor housing and cleaned. See maintenance section for cleaning instructions. To protect the pendulum from damaged due to mechanical shocks, the pendulum protection tube should carefully be placed in-between the flow tube and the pendulum. The sensor must be wrapped in protection material (preferably where it was shipped in) to protect it from damage.

Both the sensor and the interface box must be stored in a cool and dry place.

## 12. MALFUNCTION AND SEND FOR REPAIR

If the sensor or the interface box fails, they should be sent back to VAF Instruments for repair.

## 13. ENVIRONMENT

There are several electronics inside the Interface box. The sensor has Teflon<sup>®</sup> coating on the sensor head and the flow tube. During normal use all these components can not cause any harm to the environment.

## 14. DISPOSAL

Laws and restrictions for disposal of equipment will be different in most countries. If in doubt or unable to dispose the equipment it can be send back to VAF Instruments.


VAF Instruments will dispose the equipment in a correct way.

The ViscoSense<sup>®</sup>2 equipment has the following possible environmentally unfriendly components in minor quantities.

Sensor	Teflon <sup>®</sup> coating on the flow tube and the sensor head.
Sensor cable	Electrical cable with Teflon <sup>®</sup> coating.
Interface box	Electronic components.

## 15. TROUBLE SHOOTING

### 15.1 DISCONNECTION THE SENSOR



*Figure 17*

The sensor and electric wire are moulded together.



**NEVER TRY TO OPEN THE BACK OF THE SENSOR.**  
**THIS WILL DAMAGE THE WIRE AND SENSOR BEYOND REPAIR.**

The sensor can only be disconnected at the interface box.

## 15.2 GENERAL TROUBLE SHOOTING

Problem	Possible cause	Corrective action
No viscosity signal	No supply to interface box	Check supply. Check fuses. Check electrical connections.
	Current loop connection broken	Check electrical wiring of 4-20 mA output signal
	Air entrapped in the fuel system	Vent the system
	ViscoSense®2 malfunctioning	Check diagnostic led
No temperature signal	No supply to interface box	Check supply. Check fuses. Check electrical connections.
	Current loop connection broken	Check electrical wiring of 4-20 mA output signal
	ViscoSense®2 malfunctioning	Check diagnostic led
Viscosity output is lower than expected	Actual viscosity is lower than expected. E.g. bunker calculator only gives approx. value. Dilution with MDO. Temperature is higher than expected.	None (For laboratory check of viscosity take sample according instructions in chapter 15.4).
	Range settings ViscoSense®2 and readout unit do not match	Check mA signal and range settings
	Air entrapped in the fuel system	Vent the system

Problem	Possible cause	Corrective action
Viscosity output is higher than expected	Actual viscosity is higher than expected. E.g. bunker calculator only gives approx. value. Temperature is lower than expected.	None (For laboratory check of viscosity take sample according instructions in chapter 15.4).
	Range settings ViscoSense <sup>®</sup> 2 and readout unit do not match	Check mA signal and range settings
	Fuel is not pure, well mixed liquid (see chapter 6)	None
	Sensor is damaged or fouled	Clean and inspect the sensor (see chapter 8)
Viscosity output is max range	The viscosity in the sensor housing is higher than the max range	Heat up the fluid
	Actual viscosity is higher than expected. E.g. bunker calculator only gives approx. value.	None
	ViscoSense <sup>®</sup> 2 interface box is malfunctioning	Check diagnostic led
	ViscoSense <sup>®</sup> 2 sensor is malfunctioning	
	Range settings ViscoSense <sup>®</sup> 2 and readout unit do not match	Check mA signal and range settings
	Sensor is damaged or fouled	Clean and inspect the sensor (see chapter 8)

### 15.3 PI SETTING ERRORS (FOR ADDITIONAL VISCOSITY CONTROLLER)

The heaters in the booster system are controlled by a viscosity controller. In order to get a good working viscosity system an optimum adaptation of the control parameters (P,I) is necessary.

P = Proportional band Pb (%)  
I = intergral action time Ti (min)

Problem	Possible cause	Corrective action
Oscillating temperature with distinct initial overshoot	Pb too low	Increase Pb
Set point is reached very slowly after initial exceeding	Pb too high	Decrease Pb
The set value is reached very slowly without overshooting	Ti too high	Decrease Ti
High initial overshoot followed by fading oscillation	Ti too low	Increase Ti

#### 15.4 HOW TO TAKE A HFO SAMPLE FOR ANALYSIS

The HFO sample must always be taken from the circulation system as close as possible to the viscosity sensor. Never take a sample from the bunker, settle or day tank.

The HFO sample must be collected and stored in a clean bottle or sample container. The bottle or sample container must be sealed in order to prevent contamination with other products. The sample quantity must be at least 200ml.

Write down the actual viscosity and temperature reading when the sample is taken. Send the sealed bottle or sample container with actual readings to a qualified laboratory or to VAF Instruments B.V. for analysis.

#### 15.5 DIAGNOSTIC INFORMATION

The printed circuit board inside the ViscoSense<sup>®</sup>2 controller has a provision for diagnostic indication. Failures and errors are displayed by a blinking digit or character on a 7 segment LED. Dependent on the type of failure, error or warning, the viscosity and/or temperature outputs will go to 0, 4 or 20 mA, or will remain functioning normally.

If there is no failure, error or warning, the display indicates the state of the program by displaying a symbol (not blinking) on the display.

The following symbols are displayed during normal operation:

Display	Description
	Power on
	Initializing hardware
	VCO frequency measurement while phase is +45 degrees
	Waiting for U_receive to settle after changing setpoint

Display	Description
	Changing U-send_setpoint
	measuring at + 45 degrees (left -3 dB point)
	measuring at - 45 degrees (left +3 dB point)
	Adjusting phase

The decimal point at the bottom of the display is always on after power is on. This point is only turned off while the ViscoSense<sup>®</sup>2 is writing to EEPROM, and if no measurement is possible due to extensive external vibrations.

Normally the ViscoSense<sup>®</sup>2 electronics will try to restart the unit if a faulty situation occurs. However, if the fault is persistent contact VAF Instruments or your local authorised VAF dealer and give a detailed description of the problem that occurred and the diagnostic information indicated at the 7 segment LED.

The faults, indicated in the table below, are listed in order of priority. The faults on top of the list have the highest priority. This means that faults with a lower priority can be overwritten by faults of a higher priority.

At power-on the system is explicitly tested for failures indicated by display messages 1, 2, 3, 4, 5, 6 and 7. During normal operation these tests (except 2) run at the background.



Followed by:

Display message	Viscosity output [mA]	Temperature output [mA]	Recovery action (attempt)	Fault description
	0	0	Delay & retry	15 V power failure. Supply drops below 13 V
	0	Actual	Delay & retry	Pendulum not oscillating
	4	Actual	Delay & retry	Oscillation error
	4 4	20 4	None None	Temperature out of range (overflow) Temperature out of range (underflow)
	20 4	Actual Actual	None None	Viscosity out of range (overflow) Viscosity out of range (underflow)
	Actual Open loop	Open loop Actual	None None	Temperature output open loop Viscosity output open loop
Not all segments working after power on	Actual	Actual	Not applicable	7 - segment display defective

Any other figure or letter indicates an error in the electronics or software.

## 16. CERTIFICATES

Certificates are delivered separately.

# 17. DRAWINGS

## 17.1 VISCOSENSE<sup>®</sup>2 SENSOR AND SENSOR HOUSING

### 17.1.1 ViscoSense<sup>®</sup>2 sensor housing with sensor installed




Figure 18 Dimensions of ViscoSense<sup>®</sup>2 sensor (All dimensions in millimetres)




Figure 19 Dimensions of ViscoSense<sup>®</sup>2 sensor (All dimensions in millimetres)




Figure 20 Dimensions of ViscoSense<sup>®</sup>2 sensor (All dimensions in millimetres)

## 17.2 VISCOSENSE®2 INTERFACE BOX

### 17.2.1 ViscoSense®2 interface box




Figure 21 Dimensions of ViscoSense®2 interface box (All dimensions in millimetres)

## 18. ABBREVIATIONS

ANSI	American National Standards Institute
AWG	American Wire Gauge
dia	Diameter
DIN	Deutsches Institut für Normung
DN	Diameter Nominal
EEPROM	Electrically Erasable Programmable Read-Only Memory
EPROM	Erasable Programmable Read-Only Memory
Hz	Hertz (Frequency)
IEC	International Electrotechnical Commission
IOM	Installation, Operation and Maintenance
JIS	Japanese Industrial Standard
Kg	Kilograms
LED	Light Emitting Diode
mPa.s	Millipascal second
PAL	Programmable Array Logic
PT100	Temperature Sensor
RAM	Random Access Memory
RH	Relative Humidity
VAC	Volt Alternating Current
°C	Degrees Centigrade

# 19. PARTS LISTS

Spare parts:

0279-0096PH consisting of 0279-0096 ViscoSense<sup>®</sup>2 sensor  
0279-0102 dongle

## 19.1 VISCOSENSE<sup>®</sup>2 SENSOR




Figure 22 Parts list

## 20. WARRANTY CONDITIONS

1. Without prejudice to the restrictions stated hereinafter, the contractor guarantees both the soundness of the product delivered by him and the quality of the material used and/or delivered for it, insofar as this concerns faults in the product delivered which do not become apparent during inspection or transfer test, which the principal shall demonstrate to have arisen within 12 months from delivery in accordance with subarticle 1A exclusively or predominantly as a direct consequence of unsoundness of the construction used by the contractor or as a consequence of faulty finishing or the use of poor materials.
  - 1A. The product shall be deemed to have been delivered when it is ready for inspection (if inspection at the premises of the contractor has been agreed) and otherwise when it is ready for shipment.
2. Articles 1 and 1a shall equally apply to faults which do not become apparent during inspection or transfer test which are caused exclusively or predominantly by unsound assembly/installation by the contractor. If assembly/installation is carried out by the contractor, the guarantee period intended in article 1 shall last 12 months from the day on which assembly/installation is completed by the contractor, with the understanding that in this case the guarantee period shall end not later than 18 months after delivery in accordance with the terms of subarticle 1A.
3. Defects covered by the guarantee intended under articles 1, 1a and 2 shall be remedied by the contractor by repair or replacement of the faulty component either on or off the premises of the contractor, or by shipment of a replacement component, this remaining at the discretion of the contractor. Subarticle 3A shall equally apply if repair or replacement takes place at the site where the product has been assembled/installed. All costs accruing above the single obligation described in the first sentence, such as are not restricted to shipment costs, travelling and accommodation costs or disassembly or assembly costs insofar as they are not covered by the agreement, shall be paid by the principal.
  - 3A. If repair or replacement takes place at the site where the product has been assembled/installed, the principal shall ensure, at his own expense and risk, that:
    - a. the employees of the contractor shall be able to commence their work as soon as they have arrived at the erection site and continue to do so during normal working hours, and moreover, if the contractor deems it necessary, outside the normal working hours, with the proviso that the contractor informs the principal of this in good time;
    - b. suitable accommodation and/or all facilities required in accordance with government regulations, the agreement and common usage, shall be available for the employees of the contractor;
    - c. the access roads to the erection site shall be suitable for the transport required;
    - d. the allocated site shall be suitable for storage and assembly;
    - e. the necessary lockable storage sites for materials, tools and other goods shall be available;
    - f. the necessary and usual auxiliary workmen, auxiliary machines, auxiliary tools, materials and working materials (including process liquids, oils and greases, cleaning and other minor materials, gas, water, electricity, steam, compressed air, heating, lighting, etc.) and the measurement and testing equipment usual for in the business operations of the principal, shall be available at the correct place and at the disposal of the contractor at the correct time and without charge;

- g. all necessary safety and precautionary measures shall have been taken and adhered to, and all measures shall have been taken and adhered to necessary to observe the applicable government regulations in the context of assembly/installation;
  - h. the products shipped shall be available at the correct site at the commencement of and during assembly.
4. Defects not covered by the guarantee are those which occur partially or wholly as a result of:
    - A. non-observance of the operation and maintenance instructions or other than foreseeable normal usage;
    - B. normal wear and tear;
    - C. assembly/installation by third parties, including the principal;
    - D. the application of any government regulation regarding the nature or quality of the material used;
    - E. materials or goods used in consultation with the principal;
    - F. materials or goods provided by the principal to the contractor for processing;
    - G. materials, goods, working methods and constructions insofar as are applied at the express instruction of the principal, and materials or goods supplied by or on behalf of the principal.
    - H. components obtained from third parties by the contractor insofar as that party has given no guarantee to the contractor.
  5. If the principal fails to fulfil any obligation properly or on time ensuing from the agreement concluded between the principal and the contractor or any agreement connected to it, the contractor shall not be bound by any of these agreements to any guarantee regardless of how it is referred to. If, without previous written approval from the contractor, the principal commences disassembly, repair or other work on the product or allows it to be commenced, then every agreement with regard to guarantee shall be void
  6. Claims regarding defects must be submitted in writing as quickly as possible and not later than 14 days after the discovery of such. All claims against the contractor regarding faults shall be void if this term is exceeded. Claims pertaining to the guarantee must be submitted within one year of the valid complaint on penalty of invalidity.
  7. If the contractor replaces components/products under the terms of his guarantee obligations, the replaced components/products shall become the property of the contractor.
  8. Unless otherwise agreed, a guarantee on repair or overhaul work carried out by the contractor or other services shall only be given on the correctness of the manner in which the commissioned work is carried out, this for a period of 6 months. This guarantee only covers the single obligation of the contractor to carry out the work concerned once again in the event of unsound work. In this case, subarticle 3A shall apply equally.
  9. No guarantee shall be given regarded the inspection conducted, advice given and similar matters.
  10. Alleged failure to comply with his guarantee commitments on the part of the contractor shall not absolve the principal from his obligations ensuing from any agreement concluded with the contractor.
  11. No guarantee shall be given on products which form a part of, or on work and services on, goods older than 8 years.

## 21. ENCLOSURE

### 21.1 RECOMMENDATIONS FOR A GOOD WORKING BOOSTER UNIT

In order to get a good working booster unit we would like to point out a few things that are important.

#### Circulation

- The capacity of one circulation/booster pump should be 2,5 to 4 times the max fuel consumption
- The capacity of one feeder pump should be 1,5 to 2 times the max fuel consumption

#### Fuel velocity

Fuel velocity depends on the capacity of the circulation/booster pump and the inner diameter of the pipe that is used. A larger inner diameter will give a slower fuel velocity.

- The recommended fuel velocity in the booster unit is 1 - 2 m/sec
- The recommended fuel velocity to and from the engines is 0,25 – 1,5 m/sec

Remarks:

- A too high fuel velocity will result in larger pressure losses within the booster unit.
- A too high fuel velocity can result in unstable viscosity measurements.
- A too low fuel velocity will result in a slow and possibly unstable viscosity control

VAF Instruments delivers the ViscoSense®2 with housing. Refer to the table below for flow rate corresponding to the size of housing:

Fluid flow rate in piping (Recommended for correct control function)	All at 0-50 mPa.s 2" - Max 20 m <sup>3</sup> /h, Min 7m <sup>3</sup> /h 2.5" - Max 34 m <sup>3</sup> /h, Min 12m <sup>3</sup> /h 3" - Max 51 m <sup>3</sup> /h, Min 18m <sup>3</sup> /h 4" - Max 80 m <sup>3</sup> /h, Min 28m <sup>3</sup> /h For lower flowrates a smaller pipe diameter is recommended.
---	---

#### Mixing tank

The mixing tank is an important part of the booster system that has several functions.

- The mixing of MDO and HFO to a homogeneous emulsion.
- The mixing of hot ( +/- 130° C ) with colder (+/- 80 °C ) fuel, to a fuel with a single temperature
- Compensation of pressure pulses
- Prevention of a thermal shock of the engine when changing over from HFO to MDO.

Remarks

- If hot and cold HFO is not mixed well, it can result in incorrect viscosity measurements, which will result in an incorrect viscosity control of the system
- High or constant pressure pulses in the system can lead to damage to the ViscoSense®2 or other components of the booster unit.

### **Fuel filters**

There should be two fuel filters, placed parallel. One should be clean and on standby.

Fuel filters should be placed in the HFO supply to the booster.

- The fuel flow is less; therefore the filter can be smaller.
- The fuel temperature is lower and the fuel is more stable.

### **Heaters**

Heaters can be steam, or electric.

There must be two heaters placed parallel in the system. Only one heater should be switched on. The other one should be clean and on standby.

### **Booster pump**

There should be two booster pumps.

One active and the other one on standby

Revision 1207:

1. Chapter 2.2, 13 and 14 Minor word choices changed
2. Chapter 15.2 corrected

Revision 0509:

Chapter 9.2 (replacement) added.  
In chapter 19 spare parts added

Revision 0709:

Chapter 9.2 note added.



VAF Instruments B.V.  
Amstelwijckweg 21, 3316 BB Dordrecht (Sales/Office)  
Pieter Zeemanweg 131, 3316 GZ Dordrecht (Warehouse/Factory)  
P.O.Box 40, 3300 AA Dordrecht, The Netherlands  
Telephone : +31 78 6183100  
Fax : +31 78 6177068  
Internet : [www.vaf.nl](http://www.vaf.nl) or [www.vaf.eu](http://www.vaf.eu)  
E-mail : [sales@vaf.nl](mailto:sales@vaf.nl)



Specifications subject to change without notice.  
Agents and distributors in more than 50 countries

Represented by: